





## KL-0039-.. Universal Wheel Bearing Tool Series



**Operating instructions** EN  
 ⚠ Read and understand before use!



[www.gedore-automotive.com](http://www.gedore-automotive.com)



**GEDORE Automotive GmbH**  
 Breslauer Straße 41  
 78166 - Donaueschingen  
 Postfach 1329  
 78154 Donaueschingen - GERMANY

☎ +49 (0) 771 / 8 32 23-0  
 ☎ +49 (0) 771 / 8 32 23-90  
 ✉ info.gam@gedore.com  
 🌐 gedore-automotive.com

**GEDORE TOOLS, INC.**

Only for USA, Canada & Mexico / Sólo para EE.UU., Canadá y México  
 Seulement pour les USA, le Canada et le Mexique  
 7187 Bryhawke Circle, Suite 700  
 North Charleston, SC 29418, USA

☎ +1-843 / 225 50 15  
 ☎ +1-843 / 225 50 20  
 ✉ info@gedoretools.com  
 🌐 gedore.com

Version 01/2023

0039-..Radlager\_EN221017.indd



**ENGLISH**

**EN**

## Address of the manufacturer

**GEDORE Automotive GmbH**

Breslauer Straße 41 // 78166 Donaueschingen - GERMANY

☎ +49 (0)771/83223-71 // ✉ info.gam@gedore.com

## Imprint

In the course of improvement and adaptation to the state of the art, we reserve the right to make changes with regard to appearance, dimensions, weights and properties, and performance.

This does not imply any claim to correction or subsequent delivery of already delivered products. Deletions can be made at any time without any legal claim arising.

Instructions for use and safety are not binding. They never substitute for any legal or trade association regulations.

We do not accept any liability for printing errors.

Any reproduction, in whole or in part, requires the prior written consent of **GEDORE Automotive GmbH**.

All rights reserved worldwide.

© Copyright by **GEDORE Automotive GmbH** Donaueschingen (GERMANY)

We refer to our general terms and conditions, which can be found in the imprint at:

[www.gedore-automotive.com](http://www.gedore-automotive.com)



## Contents

<b>1. READ AND UNDERSTAND FOR YOUR SAFETY</b> .....	<b>4</b>
1.1 Target group.....	4
1.2 Obligations of the owner.....	4
1.3 Intended use .....	4
1.4 Reasonably foreseeable misuse .....	4
1.5 Personal protective equipment.....	5
1.6 Labelling of the warnings.....	5
1.7 Basic warnings .....	5
1.8 Basic safety instructions .....	6
1.9 Work environment .....	7
1.10 Emissions.....	7
1.11 Maintenance .....	7
1.12 Troubleshooting.....	7
<b>2. PRODUCT DESCRIPTION</b> .....	<b>8</b>
2.1 KL-0039-.. Wheel bearing tool series .....	8
2.2 Scope of delivery / Single parts overview / Specifications.....	10
<b>3. PREPARATION</b> .....	<b>13</b>
3.1 Checking the scope of delivery .....	13
3.2 Assembling drive parts .....	13
3.3 Preparing the pulling device.....	14
3.4 Preparing the vehicle .....	14
<b>4. TYPICAL APPLICATIONS</b> .....	<b>15</b>
4.1 Forcing out and in by means of <u>pull device</u> .....	16
Forcing out wheel bearings.....	16
Forcing in wheel bearings .....	18
Forcing in wheel hub .....	20
4.2 Forcing out and in by means of <u>stand press</u> .....	22
Forcing out wheel bearings.....	22
Forcing in wheel bearings .....	24
Forcing in wheel hub .....	26
<b>5. TOOL KITS AND ACCESSORIES</b> .....	<b>28</b>
<b>6. CARE AND STORAGE</b> .....	<b>30</b>
<b>7. REPAIR</b> .....	<b>30</b>
<b>8. ENVIRONMENTALLY FRIENDLY DISPOSAL</b> .....	<b>30</b>

## 1. READ AND UNDERSTAND FOR YOUR SAFETY



Read and understand these operating instructions **before using** the wheel bearing tool, and observe all safety and warning instructions! Misuse can result in **DEATH** or **SEVERE INJURIES**! These operating instructions are an integral part of the wheel bearing tool. Keep them at a safe place for future reference, and always pass them on to subsequent users of the wheel bearing tool! The wheel bearing tool complies with the recognised rules of technology as well as the relevant safety regulations!

### 1.1 Target group

These operating instructions are **exclusively** intended for skilled personnel in specialised motor vehicle workshops!

The wheel bearing tool **may only be** used by skilled personnel in specialised motor vehicle workshops who are familiar with the basic regulations on work safety and accident prevention!

✔ **Never** allow unauthorised, inexperienced persons, minors and children, or persons with limited physical, sensory, and mental abilities to use the wheel bearing tool!

### 1.2 Obligations of the owner

Pursuant to the German Ordinance on Industrial Safety and Health (*BetrSichV*), employers are obliged to provide their employees with safe work equipment in accordance with the recognised rules of technology and the relevant safety regulations!

✔ The owner of the wheel bearing tool **must** ensure that **only** trained personnel in specialised vehicle workshops use the wheel bearing tool!

✔ The owner of the wheel bearing tool **must** ensure that the instructions for use are available to the user and that the user has completely read and understood the instructions for use **before** using the wheel bearing tool!

✔ The owner of the wheel bearing tool **must** ensure that the user is familiar with the basic regulations on work safety and accident prevention, and that the personal protective equipment is available to him/her!

### 1.3 Intended use

The wheel bearing tool ...

✔ **may only** be used for forcing out or forcing in wheel bearings!

✔ **may only** be used up to the **a max. load of 17 tonnes** or **that of the weakest component used!**

✔ **may only** be driven by hand with muscle power together with a manual drive, a manually driven strand press, or a manually operated **GEDORE Automotive** hydraulic cylinder/pump combination with a pressure gauge for safe pressure control!

✔ **may only** be used with stand presses which comply with the recognised rules of technology and the relevant provisions of the *Machinery Directive 2006/42/EC*!

✔ **may only** with genuine **GEDORE Automotive** spare parts and accessories!

✔ **may only** be used in the way described in these operating instructions!

⚠ Any other use can result in **DEATH** or **SEVERE INJURIES**!

### 1.4 Reasonably foreseeable misuse

The wheel bearing tool ...

✔ **must never** be used for forcing out or in other parts than those intended for it!

✔ **must never** be used together with an impulse or impact screwdriver!

✔ **must never** be used with a machine drive, a machine-operated stand press, or a hydraulic cylinder/pump combination, or any other drive than intended!

✔ **must never** be used for batch processing with many forcing in/out processes within a few minutes!

✔ **must never** be used with a bridged, modified, or removed safety device!

✔ **must never** be modified, converted, or used for other purposes without authorisation!

⚠ Use the wheel bearing tool **always** as intended. Any other use can result in **DEATH** or in **SEVERE INJURIES**!



### 1.5 Personal protective equipment

For your safety, **always** wear personal protective equipment when using the wheel bearing tool! The wheel bearing tool can bring about mechanical hazards, such as crushing, cutting and shock injuries.



Always wear **EYE PROTECTION** (for example to DIN EN 166, OSHA 29 CFR 1910.133, ANSI Z87) when using the wheel bearing tool to protect yourself against flying parts or particles!

When using the wheel bearing tool, flying parts or particles can cause **SEVERE INJURIES** to your **eyes**!



Always wear **PROTECTIVE GLOVES** (for example to DIN EN 388, OSHA 29 CFR 1910.138, ANSI 105) when using the wheel bearing tool to protect yourself against sharp edges and crushing between parts!

When working with the wheel bearing tool, sharp edges and crushing between parts can cause **SEVERE INJURIES** to your **hands**!



Always wear **SAFETY SHOES** (for example to DIN EN ISO 20345, OSHA 29 CFR 1910.136, ANSI Z41) when using the wheel bearing tool to protect yourself against dropping parts!

When working with the wheel bearing tool, dropping parts can cause **SEVERE INJURIES** to your **feet and toes**!

EN

### 1.6 Labelling of the warnings

Warnings warn of potential **hazards**. **Always** observe these warnings to avoid **DEATH** or **INJURIES**!

For better differentiation, warnings in these operating instructions are classified as follows:

Warning sign	Meaning
	Indicates a hazardous situation which, if not avoided, could cause <b>DEATH</b> or <b>SEVERE INJURIES</b> .
	Indicates a hazardous situation which, if not avoided, could cause <b>MODERATE</b> or <b>MINOR INJURIES</b> .
	Indicates a situation which, if not avoided, can cause damage to the tool or an object in its vicinity.
	<b>Note</b> on important information and useful tips.

### 1.7 Basic warnings

#### **WARNING - Danger to life from MISUSE**

**MISUSE** can cause the wheel bearing tool to break and thus drop or be hurled about. This can cause **DEATH** or **SEVERE INJURIES**!

- When using the wheel bearing tool, flying parts or particles can cause **SEVERE INJURIES** to your **eyes**!
- When working with the wheel bearing tool, sharp edges and crushing between parts can cause **SEVERE INJURIES** to your **hands**!
- When working with the wheel bearing tool, dropping parts can cause **SEVERE INJURIES** to your **feet and toes**!
- Read and understand these operating instructions **before using** the wheel bearing tool, and observe all safety and warning instructions for **safe use**!
- Always** work with the wheel bearing tool in accordance with the basic regulations on work safety and accident prevention!
- Only** use the wheel bearing tool as described in these operating instructions!
- Always** observe the vehicle-specific application procedures in the vehicle manufacturer's repair guide!
- Never** use the wheel bearing tool if it is damaged or has loose parts or unauthorised modifications!
- Never** use the wheel bearing tool with an impulse or impact wrench!
- Never** use the wheel bearing tool with a machine-operated drive. Drive it **exclusively** by hand with muscle power with a manual drive, or a manually driven stand press or **GEDORE Automotive** hydraulic cylinder/pump combination with pressure gauge for safe pressure control!
- Never** use the wheel bearing tool for batch processing with numerous forcing in/out processes within a few minutes!
- Always** wear your personal protective equipment (*safety goggles, protective gloves, safety shoes*) during work!
- Never** hit the wheel bearing tool with a hammer or anything similar!

## ⚠ WARNING - Danger to life from OVERLOAD

**OVERLOADING** can cause the wheel bearing tool to break and thus drop or be hurled about. This can cause **DEATH** or **SEVERE INJURIES!**

- ✔ **Never** exceed the **maximum load** of the wheel bearing tool or the individual components!
- ✔ **Never** use the wheel bearing tool if it is damaged or has loose parts or unauthorised modifications!
- ✔ **Never** use the wheel bearing tool with an impulse or impact wrench!
- ✔ **Never** use the wheel bearing tool with a machine-operated drive. Drive it **exclusively** by hand with muscle power with a manual drive, or a manually driven stand press or **GEDORE Automotive** hydraulic cylinder/pump combination with pressure gauge for safe pressure control!
- ✔ **Never** use the wheel bearing tool for batch processing with numerous forcing in/out processes within a few minutes!
- ✔ **Always** wear your personal protective equipment (*safety goggles, protective gloves, safety shoes*) during work!

## ⚠ WARNING - Danger of injury from FALLING

There is a risk of the wheel bearing tool **DROPPING** during preparation and use (overhead, for example). This can cause **SEVERE INJURIES** at the head!

- ✔ Before use, **always** secure the wheel bearing tool against falling off the vehicle or axle, e.g. using the safety retaining belt available as an accessory - **KL-0040-2590** or **KL-0040-2592!**
- ✔ Avoid dropping the wheel bearing tool **under any circumstances!**
- ✔ **Always** make sure that the wheel bearing tool is securely attached to the vehicle!
- ✔ **Never** leave the wheel bearing tool unattended in loaded condition on the vehicle or the wheel bearing!
- ✔ Put down the wheel bearing tool **safely** to prevent it from dropping (for example on a workbench)!
- ✔ **Always** carry out necessary preparations of heavy parts with the help of a second specialist!
- ✔ **Always** wear your personal protective equipment (*safety goggles, protective gloves, safety shoes*) during work!

## ATTENTION - Risk of DAMAGE

Vehicle, wheel bearing, wheel bearing housing, and the wheel bearing tool can be **DAMAGED**.

- ✔ **Always** install the wheel bearing and the wheel hub in the installation position specified by the manufacturer!
- ✔ **Always** observe the vehicle-specific application procedures in the vehicle manufacturer's repair guide.
- ✔ **Prior to each use**, check the moving parts and the spindle of the wheel bearing tool for sufficient lubrication. If necessary, lubricate them **only** with molybdenum disulphide paste (*for example, with GEDORE KL-0014-0030!*)
- ✔ **Never** use the wheel bearing tool for batch processing with numerous forcing in/out processes within a few minutes!
- ✔ **Never** clamp the wheel bearing tool in a vice.

## 1.8 Basic safety instructions

For your safety, **always** observe the following safety precautions when using the wheel bearing tool in order to avoid injuries and material damage caused by misuse or unsafe handling.

- ✔ Read and understand these operating instructions **before using** the wheel bearing tool, and observe all safety and warning instructions for **safe use!**
- ✔ **Always** observe the vehicle-specific application procedures in the vehicle manufacturer's repair guide!
- ✔ **Always** work with the wheel bearing tool in accordance with the basic regulations on work safety and accident prevention!
- ✔ **Never** use the wheel bearing tool when you are tired or under the influence of alcohol, drugs, or medication!
- ✔ **Before each use**, check the wheel bearing tool **carefully** for damage, loose parts, or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- ✔ Use **only genuine GEDORE Automotive** spare parts and accessories!
- ✔ **If necessary**, carry, lift, and position the wheel bearing tool with the help of a second specialist due to its weight!
- ✔ **Before using** the wheel bearing tool, make sure that **no** unauthorised persons are in the immediate environment!
- ✔ **Always** observe the **max. loading capacity** when using the wheel bearing tool and the individual components, and **never** exceed it!
- ✔ **Never** stand in the axial extension of the wheel bearing tool when it is under load!

- ✔ **Never** use the wheel bearing tool with an unauthorised drive. Drive it **only** with an approved drive!
- ✔ **Always** wear your personal protective equipment (*safety goggles, protective gloves, safety shoes*) during work!
- ✔ Interrupt your work **immediately** if you are unsure about using the wheel bearing tool, and contact **GEDORE Automotive GmbH if necessary!**
- ✔ For safety reasons, ensure that a damaged wheel bearing tool is no longer used! Professional inspection and repair may only be carried out by specially trained personnel from **GEDORE Automotive GmbH**.
- ✔ **Always** use the wheel bearing tool as intended. Non-compliance will invalidate any warranty claim and may significantly reduce its durability!

## 1.9 Work environment

For your safety, **only** use the wheel bearing tool in a safe working environment.

- ✔ The workplace **must** be clean and tidy.
- ✔ The workplace **must** be sufficiently large and illuminated.
- ✔ The workplace **must** be on a solid and non-skidding floor.
- ✔ The workplace **must** be safeguarded against access of unauthorised persons.
- ✔ The workplace **must** have a room temperature between -10°C and +40°C.

## 1.10 Emissions

Molybdenum disulphide paste and hydraulic oil can drip or escape when using the wheel bearing tool and thus pose a hazard to the environment.

- ✔ **Immediately** remove leaking hydraulic oil as well as excess molybdenum disulphide paste (using oil binding agents or a rag, for example).
- ✔ In case of skin contact with hydraulic oil, clean the affected area **immediately** with degreasing soap and water.
- ✔ Dispose of pollutants such as hydraulic oil and molybdenum disulphide paste in an **environmentally friendly** manner.
- ✔ Safety data sheets *in accordance with Regulation (EC) No. 1907/2006*, for hydraulic oil (**Alsus Hyd HLP 32**) as well as for molybdenum disulphide paste (**MOLYKOTE(R) G-N PLUS PASTE**) can be found on the manufacturer's site on the Internet (**World Wide Web**) or, if required, contact **GEDORE Automotive GmbH**.

## 1.11 Maintenance

Perform maintenance on the wheel bearing tool **at regular intervals** and **only** when the tool is tension-free and/or depressurised! Poor and improper maintenance can damage the wheel bearing tool, thus causing **DEATH** or **SEVERE INJURIES!**

**Prior to each use:**

- ✔ **Prior to each use**, check the wheel bearing tool **carefully** for damage, loose parts or unauthorised modifications!
- ✔ **Prior to each use** of the wheel bearing tool, check the spindles for contamination and damage. If necessary, clean them, and subsequently lubricate them **only** with molybdenum disulphide paste! (For example, **GEDORE Automotive** molybdenum disulphide paste - **KL-0014-0030**)

**Recommended: Every 24 months:**

- ✔ Have the wheel bearing tool professionally checked **every 24 months** by authorised **GEDORE Automotive GmbH** specialists!

## 1.12 Troubleshooting

Perform troubleshooting on the wheel bearing tool **only** when it is tension-free/depressurised!

**Problem:** The spindle's clamping nut on the wheel bearing tool is sluggish. (*Mechanical drive*)

**Reason:** The spindle is contaminated or insufficiently lubricated, or wrong lubricant was used.

**Remedy:** Clean the spindle, check it for damage, and lubricate it **only** with molybdenum disulphide paste. (For example, **GEDORE Automotive** molybdenum disulphide paste - **KL-0014-0030**)

**Problem:** Hydraulic oil escapes from the hydraulic coupling between hydraulic cylinder and hand pump.

**Reason:** Hydraulic coupling contaminated or loose.

**Remedy:** Clean and retighten the hydraulic coupling. Top up lacking hydraulic oil (**HLP 32**) at the hand pump.

## 2. PRODUCT DESCRIPTION

### 2.1 - KL-0039-.. Wheel bearing tool series

With the modular system of the **KL-0039-..wheel bearing tool series**, wheel bearings can be forced out and in, and wheel hubs can be forced out by means of a pulling device directly on the vehicle. Alternatively, it can also be used on a suitable stationary stand press.


The special design of the thrust washers which are offset on one side, ensures precise force transmission directly to the wheel bearing outer ring or inner ring, thus preventing damage to the new wheel bearing.

The combination of centring and thrust rings results in thrust pieces which can be precisely matched to the corresponding wheel bearing diameter.


For this purpose, the modular system can be individually assembled depending on the wheel bearing diameter or wheel hub diameter, for example to...

EN


...force out to the wheel bearing by means of a pulling device.



...force in a the wheel bearing by means of a pulling device.




...force in a wheel hub by means of a pulling device.




- A** = Hydraulic cylinder
- B** = Retaining adapter
- D** = Clamping nut
- C** = Pull spindle
- E** = Adapter ring
- F** = Bearing cover
- G** = Housing
- H** = Support ring
- I** = Centring ring
- J** = Thrust ring


... force out a wheel bearing  
by means of a pulling stand.



... force in a wheel bearing  
by means of a pulling stand.



... force in a wheel hub  
by means of a pulling stand.





## 2.2 Scope of delivery/single parts overview Specifications

Wheel bearing tool sets (see chapter 5.)

① This table shows the basic components of the **KL-0039-..Wheel bearing tool series**.  
Other accessories see GEDORE Automotive catalogue!


		KL-0039-0110 K	KL-0039-0101	KL-0039-8131 E	KL-0039-814 E	KL-0039-807 B	KL-0039-140	KL-0039-801 C	KL-0039-802	KL-0039-1920	KL-0039-2120	
<b>Foam inserts...</b>												
	<b>Item</b>											
KL-4999-1313 - Foam insert	-			•								
KL-4999-1314 - Foam insert	-				•							
<b>Plastic case...</b>												
KL-0039-0119 - Plastic case	-	•										
KL-4999-1392 - Plastic case	-			Accesso- ries	Accesso- ries							
<b>Molybdenum disulphide paste...</b>												
KL-0014-0030 - Molybdenum disulphide paste	-	•										
<b>Hydraulic cylinder... A (max. load 17t)</b>												
KL-0040-2500 - Hydraulic cylinder	A1											
<b>Mounting adapter... B</b>												
KL-0039-1002 - Mounting adapter for clamping nut + thrust spindle	B1	•						•	•			
KL-0039-1003 - Mounting adapter for hydraulic cylinder	B2								•			
KL-0039-1011 - Mounting adapter for mech. spindle	B3	•						•				
<b>Draw spindles... C (max. load 20t)</b>												
KL-0040-3008 - Pulling spindle M20, 290mm, mechanical drive	C1	•										
KL-0039-2030 - Pulling spindle M20, 420mm, mechanical drive	C2							•				
KL-0039-1920-1 A - Pulling spindle M20, 590mm, hydraulic drive	C3								•	•	•	
<b>Clamping nuts... D (max. load 20t)</b>												
KL-0040-3009 - Clamping nut M20	D1	•							•	•		
KL-0039-2120-2 - Quick-clamping nut M20	D2							•			•	
<b>Adapter rings... E</b>												
KL-0039-1503 - Adapter ring conical Ø 74/99mm, 39mm	E1				•	•						
KL-0039-1504 - Adapter ring, conical Ø 74/99mm, 44mm	E2				•	•						
KL-0039-1505 - Adapter ring, cylindrical Ø 84/104mm, 53mm	E3				•	•						
KL-0039-1509 - Adapter ring, cylindrical Ø 85/104mm, 45mm	E4				•	•						
<b>Bearing cover... F</b>												
KL-0039-1401 - Bearing cover	F1	•		•			•					
<b>Housing... G</b>												
KL-0039-1402 - Housing Ø 90mm	G1	•		•		•	•					
KL-0039-1403 - Housing Ø 100mm	G2				•							
<b>Support rings... H</b>												
KL-0039-1413 - Support ring Ø 70mm	H1	•		•			•					
KL-0039-1414 - Support ring Ø 75mm	H2	•		•			•					
KL-0039-1415 - Support ring Ø 80mm	H3	•		•			•					
		... Continued on the following page!										

		KL-0039-0110 K	KL-0039-0101	KL-0039-8131 E	KL-0039-814 E	KL-0039-807 B
<b>Centring rings... [I]</b>	<b>Item</b>					
KL-0039-1325 - Centring ring Ø 25mm	I1				•	
KL-0039-1326 - Centring ring Ø 26mm	I2				•	
KL-0039-1327 - Centring ring Ø 27mm	I3				•	
KL-0039-1328 - Centring ring Ø 28mm	I4				•	
KL-0039-1329 - Centring ring Ø 29mm	I5				•	
KL-0039-1330 - Centring ring Ø 30mm	I6				•	
KL-0039-1331 - Centring ring Ø 31mm	I7				•	
KL-0039-1332 - Centring ring Ø 32mm	I8				•	
KL-0039-1333 - Centring ring Ø 33mm	I9				•	
KL-0039-1334 - Centring ring Ø 34mm	I10	•	•	•		
KL-0039-1335 - Centring ring Ø 35mm	I11				•	
KL-0039-1336 - Centring ring Ø 36mm	I12				•	
KL-0039-1337 - Centring ring Ø 37mm	I13				•	
KL-0039-1338 - Centring ring Ø 38mm	I14	•	•	•		
KL-0039-1339 - Centring ring Ø 39mm	I15	•	•	•		
KL-0039-1340 - Centring ring Ø 40mm	I16	•	•	•		
KL-0039-1341 - Centring ring Ø 41mm	I17	•	•	•		
KL-0039-1342 - Centring ring Ø 42mm	I18	•	•	•		
KL-0039-1343 - Centring ring Ø 43mm	I19	•	•	•		
KL-0039-1344 - Centring ring Ø 44mm	I20				•	
KL-0039-1345 - Centring ring Ø 45mm	I21	•	•	•		
KL-0039-1346 - Centring ring Ø 46mm	I22				•	
KL-0039-1347 - Centring ring Ø 47mm	I23				•	
KL-0039-1348 - Centring ring Ø 48mm	I24				•	
KL-0039-1349 - Centring ring Ø 49mm	I25				•	
KL-0039-1350 - Centring ring Ø 50mm	I26				•	
KL-0039-1351 - Centring ring Ø 51mm	I27				•	
KL-0039-1352 - Centring ring Ø 52mm	I28				•	
KL-0039-1353 - Centring ring Ø 53mm	I29				•	
KL-0039-1354 - Centring ring Ø 54mm	I30				•	
KL-0039-1355 - Centring ring Ø 55mm	I31				•	
KL-0039-1356 - Centring ring Ø 56mm	I32				•	
KL-0039-1357 - Centring ring Ø 57mm	I33				•	
KL-0039-1358 - Centring ring Ø 58mm	I34				•	
KL-0039-1359 - Centring ring Ø 59mm	I35				•	
KL-0039-1360 - Centring ring Ø 60mm	I36				•	
KL-0039-1506 - Centring ring Ø 60mm e.g. for stand press	I37			•		•
<b>Thrust rings... [J]</b>						
KL-0039-1254 - Thrust ring Ø 54mm	J1				•	
KL-0039-1260 - Thrust ring Ø 60mm	J2	•	•	•		
KL-0039-1261 - Thrust ring Ø 61mm	J3				•	
KL-0039-1262 - Thrust ring Ø 62mm	J4				•	
KL-0039-1263 - Thrust ring Ø 63mm	J5				•	
KL-0039-1264 - Thrust ring Ø 64mm	J6	•	•	•		
KL-0039-1265 - Thrust ring Ø 65mm	J7				•	
KL-0039-1266 - Thrust ring Ø 66mm	J8				•	
KL-0039-1267 - Thrust ring Ø 67mm	J9				•	
KL-0039-1268 - Thrust ring Ø 68mm	J10	•	•	•		
KL-0039-1269 - Thrust ring Ø 69mm	J11				•	
KL-0039-1270 - Thrust ring Ø 70mm	J12				•	
KL-0039-1271 - Thrust ring Ø 71mm	J13				•	
KL-0039-1272 - Thrust ring Ø 72mm	J14	•	•	•		
KL-0039-1273 - Thrust ring Ø 73mm	J15				•	
KL-0039-1274 - Thrust ring Ø 74mm	J16	•	•	•		
KL-0039-1275 - Thrust ring Ø 75mm	J17				•	
KL-0039-1276 - Thrust ring Ø 76mm	J18				•	
KL-0039-1277 - Thrust ring Ø 77mm	J19				•	
KL-0039-1278 - Thrust ring Ø 78mm	J20				•	
KL-0039-1279 - Thrust ring Ø 79mm	J21				•	
KL-0039-1280 - Thrust ring Ø 80mm	J22	•	•	•		
KL-0039-1281 - Thrust ring Ø 81mm	J23				•	
KL-0039-1282 - Thrust ring Ø 82mm	J24	•	•	•		
KL-0039-1283 - Thrust ring Ø 83mm	J25				•	
KL-0039-1284 - Thrust ring Ø 84mm	J26				•	
KL-0039-1285 - Thrust ring Ø 85mm	J27	•	•	•		
KL-0039-1286 - Thrust ring Ø 86mm	J28				•	
KL-0039-1287 - Thrust ring Ø 87mm	J29				•	
KL-0039-1288 - Thrust ring Ø 88mm	J30				•	
KL-0039-1289 - Thrust ring Ø 89mm	J31				•	
KL-0039-1290 - Thrust ring Ø 90mm	J32				•	
KL-0039-1296 - Thrust ring Ø 96mm	J33			•		
KL-0039-1501 - Thrust ring Ø 95mm with recess for ABS sensor	J34				•	


**A = Hydraulic cylinders**




**E = Adapter rings**



**F = Bearing covers**




**G = Housings**




**H = Support rings**



**B = Retaining adapter**




**I = Centring rings**



**C = Pull spindles**



**J = Thrust rings**



**D = Clamping nuts**



### 3. PREPARATION

#### **⚠ WARNING**

The wheel bearing tool can slip, break and fall or be thrown around as a result of **incorrect use** or **overloading**. This can cause **DEATH** or **SEVERE INJURIES!**

- ✔ **Prior to using** the wheel bearing tool, read and understand **all** safety instructions and warnings listed in **Chapter 1** and **always observe** them **for safe use!**
- ✔ Use the wheel bearing tool **as intended** and **always** carry out maintenance and repair work in compliance with the regulations on occupational safety and accident prevention as well as the vehicle manufacturer's instructions!
- ✔ **Before each use**, check the wheel bearing tool **carefully** for damage, loose parts, or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- ✔ **Always** wear your personal protective equipment (*such as safety goggles, protective gloves, safety shoes*) during work!

#### 3.1 Checking the scope of delivery

Prior to preparing or using the wheel bearing tool, check that all parts of the scope of delivery are available (*see chapter 2.*), and follow the instructions below.

#### 3.2 Assemble drive parts for traction device

#### **⚠ WARNING**


Using a machine-operated drive can cause the wheel bearing tool to break and thus drop or be hurled about. This can cause **DEATH** or **SEVERE INJURIES!**

- ✔ **Never** use the wheel bearing tool with a machine-operated drive. Drive it **exclusively** by hand with muscle power with a manual drive, or a manually driven **GEDORE Automotive** hydraulic cylinder/pump combination with pressure gauge for safe pressure control!
- ✔ **Never** use the wheel bearing tool with an impulse or impact wrench!

1. When using the pulling device, assemble all the required drive parts for the wheel bearing tool as shown in **📷 1**.

① *For other pressure plates see the GEDORE Automotive catalogue.*

**📷 1:** Required drive parts for the pulling device







## 3.3 Preparing the pulling device

**📷2:** Preparing the pulling device...

... with **hydraulic** drive parts



... with **mechanical** drive parts




1. Assemble the bearing block tool accordingly depending on the drive type, either **hydraulic** or **mechanical**.

ⓘ The safety harnesses **KL-0040-2590** or **KL-0040-2592**, which are available as an *accessory*, enable the securing of the wheel bearing block tool against dropping.

## 3.4 Preparing the vehicle

**📷3:** Prepare the vehicle according to the manufacturer's instructions and pull out wheel hub.



1. Safely lift the vehicle and prepare all necessary parts for the following work in accordance with the manufacturer's instructions.

**For example:**

Unscrew wheel; remove brake, drive shaft, ABS sensor; pull out the wheel hub, for example by using **KL-0174-... - puller series**; remove the circlip on the wheel bearing.




## 4. TYPICAL APPLICATIONS

The following application examples describe the forcing out and forcing in of a wheel bearing as well as the forcing in of a wheel hub in **two** different ways ...


**Typical application  
with pulling device:**

*See chapter 4.1*



**Typical application  
with stand press:**

*See chapter 4.2*



## 4.1 Forcing out and in by means of a pulling device

This application example describes the forcing out and forcing in of a wheel bearing by means of a pulling device. The process follows the same principle, both mechanically and hydraulically.

### Forcing out wheel bearings

**4:** Depending on the wheel bearing diameter, determine a suitable support ring **[H]** or adapter ring **[E]** and thrust ring **[J]**.

#### CAUTION

The wheel bearing can get stuck in the support ring **[H]** or adapter ring **[E]** when forced out!


✔ Select a support ring **[H]** or adapter ring **[E]** whose inner diameter is larger than the outer diameter of the wheel bearing!

The thrust ring **[J]** can get stuck in the wheel bearing housing when the wheel bearing is forced out, and be damaged!

✔ Select a thrust ring **[J]** whose outer diameter is smaller than the outer diameter of the wheel bearing

✔ Align the thrust ring **[J]** with the flat side facing the wheel bearing housing!

1. Depending on the wheel bearing outer diameter, determine a suitable support ring **[H]** or adapter ring **[E]**, and a thrust ring **[J]**.



**5:** Assemble the wheel bearing tool to fit and mount it in the correct position to the wheel bearing housing.

#### CAUTION


The draw spindle **[C]** can be damaged when the wheel bearing is forced out as a consequence of an inclined fit of the wheel bearing tool!

✔ Ensure that the support ring **[H]** or adapter ring **[E]** is positioned at a right angle to the wheel bearing on at least two opposing surfaces and securely seated on the wheel bearing housing!



When forcing out, the wheel bearing can collide with the support ring **[H]** or adapter ring **[E]** and the thrust ring **[J]** with the wheel bearing housing!

✔ Align the support ring **[H]** or adapter ring **[E]** and thrust ring **[J]** exactly in the centre of the wheel bearing!

2. Fix the wheel bearing tool as shown to the wheel bearing housing, either *hydraulically* or, as an alternative, *mechanically*, and with all necessary components.



**6:** Force the wheel bearing out of the wheel bearing housing in a controlled manner.



**! WARNING**

There is the risk of the wheel bearing tool breaking and flinging around when a machine-operated drive is used. This can cause **DEATH** or **SEVERE INJURIES**.

Use the wheel bearing tool **exclusively** with a manual drive or a manually operated **GEDORE Automotive** hydraulic cylinder / pump combination with a pressure gauge for reliable pressure control!

3. Connect the hydraulic pump [1] to the hydraulic cylinder [A].


**! WARNING**

When forcing out the wheel bearing, the draw spindle [C] can break, and the wheel bearing tool can fling around or fall down. This can cause **DEATH** or **SEVERE INJURIES**.

- Never exceed the **max. load of 17 tonnes** or that of the **weakest component used!**
- Constantly watch the pressure on the pressure gauge of the hydraulic pump [1] while forcing out.
- Before use, **always** secure the wheel bearing tool against flinging around or falling off the vehicle, for example by using the safety retaining harness which is available as an *accessory* - **KL-0040-2590** or **KL-0040-2592!**
- While forcing out, **never** stand in the axial extension of the draw spindle [C].

4. While operating the hydraulic pump [1], watch the pressure on the pressure gauge, and force the wheel bearing out of the wheel bearing housing.

**i** The maximum stroke of the hydraulic cylinder [A] is 50mm! As soon as it is reached: Interrupt the forcing process, relieve the pressure at the hydraulic pump [1], re-tighten the clamping nut [D] until it is fully applied, and continue the forcing process.



## Forcing in wheel bearings

**7:** According to the wheel bearing diameter, determine a matching centring ring [I] and matching thrust rings [J].

### CAUTION


The thrust collar [J] (*housing side*) can be pulled into the wheel bearing housing when forcing in the wheel bearing!

► Select a thrust ring [J] (*housing side*), whose outer diameter is larger than the outer diameter of the wheel bearing!

The thrust ring [J] (*wheel bearing side*) can get stuck in the wheel bearing housing when forcing in the wheel bearing and damage the wheel bearing!

► Select a thrust ring [J] (*wheel bearing side*) whose outer diameter is smaller than the outer diameter of the wheel bearing and rests safely on the wheel bearing outer ring!

1. Depending on the wheel bearing outer diameter, determine a suitable centring ring [I] and one thrust collar [J] each for the wheel bearing and the housing side.



**8:** Assemble the wheel bearing tool to fit and mount it in the correct position to the wheel bearing housing.

### CAUTION

The draw spindle [C] and the new wheel bearing can be damaged when the wheel bearing is forced in as a consequence of an inclined fit of the wheel bearing tool!


► Ensure that the thrust ring [J] (*housing side*) is positioned at a right angle to the wheel bearing on **at least two** opposing surfaces, and securely seated on the wheel bearing housing!

The wheel bearing can tilt on the wheel bearing housing during forcing-in, and the thrust collar [J..] (*wheel bearing side*) can collide with the wheel bearing housing!



► Align the new wheel bearing and thrust ring [J] (*wheel bearing side*) exactly centred to the wheel bearing housing!

2. Fix the wheel bearing tool as shown to the wheel bearing housing, either *hydraulically* or, as an alternative, *mechanically*, and with all necessary components and the new wheel bearing in the correct position and according to the manufacturer's instructions to the wheel bearing housing.

ⓘ The centring ring [I] facilitates centring of the wheel bearing to the pulling device and thus ensures the straightest possible forcing-in of the wheel bearing without tilting.



**9:** Force the wheel bearing into the wheel bearing housing in a controlled manner according to manufacturer's specifications.



**WARNING**

There is the risk of the wheel bearing tool breaking and flinging around when a machine-operated drive is used. This can cause **DEATH** or **SEVERE INJURIES**.

Use the wheel bearing tool **exclusively** with a manual drive or a manually operated **GEDORE** Automotive hydraulic cylinder / pump combination with a pressure gauge for reliable pressure control!

3. Connect the hydraulic pump [1] to the hydraulic cylinder [A].

**CAUTION**

The wheel bearing and any ABS sensor disc on it may be damaged when forcing in!

Be sure to observe the installation position of the wheel bearing according to the manufacturer's specifications.

When forcing in the wheel bearing, always pay attention to any ABS sensor disc which may be attached to it!

**WARNING**

When forcing in the wheel bearing, the draw spindle [C] can break, and the wheel bearing tool can fling around or fall down. This can cause **DEATH** or **SEVERE INJURIES**.

Never exceed the **max. load of 17 tonnes** or that of **the weakest component used!**


Constantly watch the pressure on the pressure gauge of the hydraulic pump [1] while forcing out.

Before use, **always** secure the wheel bearing tool against flinging around or falling off the vehicle, for example by using the safety retaining harness which is available as an *accessory* - **KL-0040-2590** or **KL-0040-2592!**

While forcing out, **never** stand in the axial extension of the draw spindle [C].

4. While operating the the pump [1], watch the pressure on the pressure gauge and force the wheel bearing out according to the manufacturer's instructions of the wheel bearing.

The maximum stroke of the hydraulic cylinder [A] is 50mm! As soon as it is reached: Interrupt the forcing process, relieve the pressure at the hydraulic pump [1], re-tighten the clamping nut [D] until it is fully applied, and continue the forcing process.





## Forcing in the wheel hub

**10:** Depending on the wheel hub diameter and the wheel bearing diameter determine a matching thrust ring [J..] and a centring ring [I].

### CAUTION

The centring ring [I] can be pulled into the wheel bearing when the wheel hub is forced in and damage the wheel bearing!


✔ Select a centring ring [I] whose outer diameter is larger than the inner diameter of the wheel bearing and rests safely on the wheel bearing inner ring!

The wheel bearing and the wheel hub can be damaged when forcing in the wheel hub!

✔ Select a thrust ring [J] whose outer diameter is larger than the *mid-centring diameter* on the wheel bearing!

✔ Place the thrust ring [J..] with its offset side on the wheel hub!

1. Depending on the wheel hub diameter, determine a matching thrust ring [J] and a matching centring ring [I] depending on the wheel bearing inner diameter.



**11:** Assemble the wheel bearing tool to fit and mount it in the correct position to the wheel bearing housing.

### CAUTION


The draw spindle [C], the wheel hub and the wheel bearing can be damaged when forcing in the wheel bearing, as a consequence of a tilted fit of the wheel bearing tool!

✔ Make sure that the wheel hub is in a straight line to the wheel bearing, and that the thrust ring [J] is at a right angle and rests safely on the wheel hub!



The wheel hub can tilt on the wheel bearing when forced in!

✔ Align the new wheel bearing and thrust ring [J] exactly centred to the wheel bearing!

2. Fix the wheel bearing tool as shown to the wheel bearing housing, either *hydraulically* or, as an alternative, *mechanically*, and with all necessary components as well as the wheel hub.



📷 **12:** Force in the wheel hub into the wheel bearing in a controlled manner according to manufacturer's specifications.



**⚠️ WARNING**

There is the risk of the wheel bearing tool breaking and flinging around when a machine-operated drive is used. This can cause **DEATH** or **SEVERE INJURIES**.

✔ Use the wheel bearing tool **exclusively** with a manual drive or a manually operated **GEDORE** Automotive hydraulic cylinder / pump combination with a pressure gauge for reliable pressure control!

3. Connect the hydraulic pump [1] to the hydraulic cylinder [A].

**CAUTION**

The wheel hub and any ABS sensor disc on it may be damaged when forcing in!

✔ **Be sure** to observe the installation position of the wheel hub according to the manufacturer's specifications!

✔ When forcing in the wheel hub, always pay attention to any ABS sensor disc which may be attached to it!

**⚠️ WARNING**

When forcing in the wheel hub, the draw spindle [C] can break, and the wheel bearing tool can fling around or fall down. This can cause **DEATH** or **SEVERE INJURIES**.

✔ **Never** exceed the **max. load of 17 tonnes** or that of **the weakest component used!**


✔ **Constantly** watch the pressure on the pressure gauge of the hydraulic pump [1] while forcing out.

✔ Before use, **always** secure the wheel bearing tool against flinging around or falling off the vehicle, for example by using the safety retaining harness which is available as an *accessory* - **KL-0040-2590** or **KL-0040-2592!**

✔ While forcing out, **never** stand in the axial extension of the draw spindle [C].

4. While operating the hydraulic pump [1], watch the pressure on the pressure gauge and force in the wheel bearing in a controlled manner according to the manufacturer's instructions.

ⓘ The maximum stroke of the hydraulic cylinder [A] is 50mm! As soon as it is reached: Interrupt the forcing process, relieve the pressure at the hydraulic pump [1], re-tighten the clamping nut [D] until it is fully applied, and continue the forcing process.



## 4.2 Forcing out and in by means of a stand press

This application example describes how to force out and force in a wheel bearing by means of a stand press.

### Forcing out wheel bearings

**13:** Depending on the wheel bearing diameter, determine a suitable support ring [H] or adapter ring [E] and thrust ring [J].

#### CAUTION

The wheel bearing can get stuck in the support ring [H] or adapter ring [E] when forced out!



✔ Select a support ring [H] or adapter ring [E] whose inner diameter is larger than the outer diameter of the wheel bearing!

The thrust ring [J] can get stuck in the wheel bearing housing when the wheel bearing is forced out, and be damaged!

✔ Select a thrust ring [J] whose outer diameter is smaller than the outer diameter of the wheel bearing

✔ Align the thrust ring [J] with the flat side facing the wheel bearing!

1. Depending on the wheel bearing outer diameter, determine a suitable support ring [H] or adapter ring [E], and a thrust ring [J].



**14:** Assemble the wheel bearing tool to fit and mount it in the correct position to the wheel bearing housing.

#### WARNING

When forcing out the wheel bearing, parts of the wheel bearing can slip off the wheel bearing tool and fling around due to an inclined fit. This can cause **DEATH** or **SEVERE INJURIES**.


✔ Ensure that the support ring [H] or adapter ring [E] is positioned at a right angle to the wheel bearing on at least two opposing surfaces and securely seated on the wheel bearing housing!

When forcing out, the wheel bearing can collide with the support ring [H] or adapter ring [E] and the thrust ring [J] with the wheel bearing housing!

✔ Align the support ring [H] or adapter ring [E] and thrust ring [J] exactly in the centre of the wheel bearing!

2. Insert the wheel bearing tool as shown with all necessary components and the wheel bearing housing on a suitable stand press.

**15:** Force the wheel bearing out of the wheel bearing housing in a controlled manner.



**⚠ WARNING**

There is the risk that the wheel bearing tool can break and fling around when a machine-operated drive is used. This can cause **DEATH** or **SEVERE INJURIES**.


- ✔ **Only** use the wheel bearing tool with a stationary press complying with the recognised rules of technology and the relevant provisions of the *Machinery Directive 2006/42/EC*!
- ✔ Use the wheel bearing tool **exclusively** with a manually operated hydraulic stand press with a manometer for reliable pressure control!

**⚠ WARNING**

When pressing out the wheel bearing, parts of the wheel bearing tool and the wheel bearing housing can slip off, break, and fling around or fall down. This can cause **DEATH** or **SEVERE INJURIES**.

- ✔ **Never** stack several parts of the wheel bearing tool which can slip against each other!
- ✔ **Never** exceed the the wheel bearing tool's **maximum load of 17 tonnes!**
- ✔ **Constantly** watch the pressure on the pressure gauge at the stand press while forcing out.
- ✔ Read and understand the operating instructions for the stand press **before using** the wheel bearing tool and observe all safety and warning instructions for **safe use!**
- ✔ **Always** work with the stand press in accordance with the basic regulations on work safety and accident prevention!

**3.** While operating the stand press, watch the pressure on the pressure gauge, and force the wheel bearing out of the wheel bearing housing.



## Forcing in wheel bearings

**16:** According to the wheel bearing diameter, determine a matching centring ring [I] and matching thrust rings [J].

### CAUTION



The thrust collar [J] (*housing side*) can be pressed into the wheel bearing housing when forcing in the wheel bearing!

► Select a thrust ring [J] (*housing side*), whose outer diameter is **larger** than the outer diameter on the wheel bearing!

The thrust ring [J] (*wheel bearing side*) can get stuck in the wheel bearing housing when forcing in the wheel bearing and damage the wheel bearing!

► Select a thrust ring [J] (*wheel bearing side*) whose outer diameter is **smaller** than the outer diameter of the wheel bearing but seats properly on the wheel bearing outer ring!

1. Depending on the wheel bearing outer diameter, determine a suitable centring ring [I] and one thrust collar [J] each for the wheel bearing and the housing side.



**17:** Assemble the wheel bearing tool to fit and mount it in the correct position to the wheel bearing housing.

### WARNING

When forcing in the wheel bearing, parts of the wheel bearing can slip off the wheel bearing tool and fling around due to an inclined fit. This can cause **DEATH** or **SEVERE INJURIES**.

► Ensure that the thrust ring [J] (*housing side*) is positioned at a right angle to the wheel bearing on **at least two** opposing surfaces, and safely seated on the wheel bearing housing!

The wheel bearing can tilt on the wheel bearing housing during forcing-in, and the thrust collar [J..] (*wheel bearing side*) can collide with the wheel bearing housing!


► Align the new wheel bearing and thrust ring [J] (*wheel bearing side*) **exactly centred** to the wheel bearing housing!

2. Fix the wheel bearing tool as shown with all necessary components, the new wheel bearing, and the wheel bearing housing **in the correct position as specified by the manufacturer** to a suitable stand press.

ⓘ The centring ring [I] facilitates centring of the wheel bearing to the stand press and thus ensures the straightest possible forcing-in of the wheel bearing without tilting.



**18:** Force the wheel bearing into the wheel bearing housing in a controlled manner according to manufacturer's specifications.



**WARNING**

There is the risk that the wheel bearing and the wheel bearing tool can slip off, break, and fling around when a machine-operated drive is used. This can cause **DEATH** or **SEVERE INJURIES**.

- **Only** use the wheel bearing tool with a stationary press complying with the recognised rules of technology and the relevant provisions of the *Machinery Directive 2006/42/EC*!
- Use the wheel bearing tool **exclusively** with a manually operated hydraulic stand press with a manometer for reliable pressure control!

**CAUTION**

The wheel bearing and any ABS sensor disc on it may be damaged when forcing in!


- **Be sure** to observe the installation position of the wheel bearing according to the manufacturer's specifications.
- When forcing in the wheel bearing, always pay attention to any ABS sensor disc which may be attached to it!

**WARNING**

When forcing in the wheel bearing, parts of the wheel bearing tool, the wheel bearing, and the wheel bearing housing can slip off, break, and fling around or fall down. This can cause **DEATH** or **SEVERE INJURIES**.

- **Never** stack several parts of the wheel bearing tool which can slip against each other!
- **Never** exceed the the wheel bearing tool's **maximum load of 17 tonnes!**
- **Constantly** watch the pressure on the pressure gauge at the stand press while forcing out.
- Read and understand the operating instructions for the stand press **before using** the wheel bearing tool and observe all safety and warning instructions for **safe use!**
- **Always** work with the stand press in accordance with the basic regulations on work safety and accident prevention!

3. Operate the stand press, watch the pressure on the pressure gauge, and force in the wheel bearing into the wheel bearing housing in a controlled manner and according to the manufacturer's instructions.



## Forcing in the wheel hub

**📷 19:** Depending on the wheel hub diameter and the wheel bearing diameter determine a matching thrust ring [J..] and a centring ring [I].

### CAUTION

The centring ring [I] can be pulled into the wheel bearing when the wheel hub is forced in and damage the wheel bearing!



✔ Select a centring ring [I] whose outer diameter is larger than the inner diameter of the wheel bearing and rests safely on the wheel bearing inner ring!

The wheel bearing and the wheel hub can be damaged when forcing in the wheel hub!

✔ Select a thrust ring [J] whose outer diameter is larger than the *mid-centring diameter* on the wheel bearing!

✔ Place the thrust ring [J..] with its offset side on the wheel hub!

1. Depending on the wheel hub diameter, determine a matching thrust ring [J] and a matching centring ring [I] depending on the wheel bearing inner diameter.



**📷 20:** Assemble the wheel bearing tool to fit and mount it in the correct position to the wheel bearing housing.

### WARNING

When forcing in the wheel hub, parts of the wheel hub can slip off the wheel bearing tool and fling around as a consequence of an inclined fit. This can cause **DEATH** or **SEVERE INJURIES**.


✔ Make sure that the wheel hub is in a straight line to the wheel bearing, and that the thrust ring [J] is at a right angle and rests safely on the wheel hub!

The wheel hub can tilt on the wheel bearing when forced in!

✔ Align the new wheel bearing and thrust ring [J] exactly centred to the wheel bearing!

2. Fix the wheel bearing tool as shown with all necessary components, the wheel hub, and the wheel bearing housing in the correct position as specified by the manufacturer into a suitable stand press.

**21:** Force in the wheel hub into the wheel bearing in a controlled manner according to manufacturer's specifications.



**⚠ WARNING**

There is the risk that the wheel bearing tool, the wheel hub, and the wheel bearing housing can slip off, break, and fling around when a machine-operated drive is used. This can cause **DEATH** or **SEVERE INJURIES**.

- ✔ **Only** use the wheel bearing tool with a stationary press complying with the recognised rules of technology and the relevant provisions of the *Machinery Directive 2006/42/EC*!
- ✔ Use the wheel bearing tool **exclusively** with a manually operated hydraulic stand press with a manometer for reliable pressure control!

**CAUTION**

The wheel hub and any ABS sensor disc on it may be damaged when forcing in!


- ✔ **Be sure** to observe the installation position of the wheel hub according to the manufacturer's specifications!
- ✔ When forcing in the wheel hub, always pay attention to any ABS sensor disc which may be attached to it!

**⚠ WARNING**

When forcing in the wheel hub, parts of the wheel bearing tool, the wheel hub, and the wheel bearing housing can slip off, break, and fling around or fall down. This can cause **DEATH** or **SEVERE INJURIES**.

- ✔ **Never** stack several parts of the wheel bearing tool which can slip against each other!
- ✔ **Never** exceed the the wheel bearing tool's **maximum load of 17 tonnes!**
- ✔ **Constantly** watch the pressure on the pressure gauge at the stand press while forcing out.
- ✔ Read and understand the operating instructions for the stand press **before using** the wheel bearing tool and observe all safety and warning instructions for **safe use!**
- ✔ **Always** work with the stand press in accordance with the basic regulations on work safety and accident prevention!

**3.** Operate the stand press, watch the pressure on the pressure gauge and force the bearing hub in according to the manufacturer's instructions.



**22:** Wheel bearing tool kit, mechanical - KL-0039-0110 K



## 5. TOOL KITS AND ACCESSORIES

**i** Further accessories and drive parts can also be found in the GEDORE Automotive catalogue!

### KL-0039-0110 K - Wheel bearing tool kit, mechanical

Universal fit for VW-Audi, BMW, Ford, Seat, Škoda, Opel/Vauxhall, etc.

Simple mechanical tool kit for forcing out and in standard wheel bearings as well as forcing in wheel hubs directly on the vehicle.

For severely stuck or corroded wheel bearings, hydraulic drive parts can also be used as an option:

**KL-0040-2500** - Hydraulic cylinder, 17t,

**KL-0215-35 M25** - Hydraulic pump,

**KL-0039-802** - Hydraulic drive

**i** Scope of supply/single part overview see **chapter 2.2**

**23:** Wheel bearing tool kit 1 - KL-0039-8131 E



### KL-0039-8131 E - Wheel bearing tool kit 1, with foam insert

Universal fit for VW-Audi, BMW, Ford, Seat, Škoda, Opel/Vauxhall, etc.

Simple wheel bearing basic tool kit without drive parts for forcing out and in standard wheel bearings as well as forcing in wheel hubs directly on the vehicle.

Fully extendible to the large wheel bearing tool kit with the **wheel bearing tool kit 2**.

**Required drive parts (mechanical):**

**KL-0039-801 C** - Mechanical drive

**Required drive parts (hydraulic):**

**KL-0040-2500** - Hydraulic cylinder, 17t

**KL-0215-35 M25** - Hydraulic pump 17t

**KL-0039-802** - Hydraulic drive

**i** Scope of supply/single part overview see **chapter 2.2**

**24:** Wheel bearing tool kit 2 - KL-0039-814 E



### KL-0039-814 E - Wheel bearing tool kit 2 with foam insert

Complete supplementary kit for **wheel bearing tool kit 1**, with many additional parts for forcing out and forcing in wheel bearings as well as forcing in wheel hubs.

**i** Scope of supply/single part overview see **chapter 2.2**



**25:** Thrust/centring ring set, 16 pieces - **KL-0039-0101**




**KL-0039-0101 - Thrust/centring ring set, 16 pieces**

Simple thrust/centring ring set without drive parts, for forcing wheel bearings out and in.

① Scope of supply/single part overview see **chapter 2.2**

**26:** Set of support rings - **KL-0039-807 B**




**KL-0039-807 B - Set of support rings**

Special support ring set without drive parts, for supporting the wheel bearing tool on wheel bearing housings with very small or uneven contact surfaces, e.g. when forcing wheel bearings out or in.

The special recesses on the support rings allow unevenness, for example by an ABS sensor, to be easily bridged.

① Scope of supply/single part overview see **chapter 2.2**

**27:** Set of housings - **KL-0039-140**



**KL-0039-140 - Set of housings**

Simple housing set without drive parts, for supporting the wheel bearing tool on conventional wheel bearing housings, for example when pulling out wheel bearings.

① Scope of supply/single part overview see **chapter 2.2**



**28: Mechanical drive kit - KL-0039-801 C**



**KL-0039-801 C - Mechanical drive kit for wheel bearing tools**

Simple mechanical drive kit for the wheel hub and wheel bearing tool kits of the **KL-0039-... series**, **KL-0041-4.. series**, and **KL-0041-380 A**.

The mounting adapter with integrated ball bearing, which is included in the kit, enables simple and force-optimised working.

The special quick-clamping nut allows the adjustment on the draw spindle without a rotary movement but only by sliding.

① Scope of supply/single part overview see **chapter 2.2**

**29: Hydraulic drive kit - KL-0039-802**



**KL-0039-802 - Hydraulic drive kit without hydraulic cylinder**

Simple hydraulic drive kit without hydraulic cylinder, for the wheel hub and wheel bearing tool kits of the **KL-0039.. series**, **KL-0041-4.. series**, and **KL-0041-380 A**.

**Required drive parts (hydraulic):**

**KL-0040-2500** - Hydraulic cylinder, 17t

**KL-0215-35 M25** - Hydraulic pump, 17t

① Scope of supply/single part overview see **chapter 2.2**

**30: Pulling spindle M20 with clamping nut - KL-0039-1920**



**KL-0039-1920 - Pulling spindle M20 with clamping nut**

① Scope of supply/single part overview see **chapter 2.2**

**31: Pulling spindle M20 with quick-clamping nut - KL-0039-2120**



**KL-0039-2120 - Pulling spindle M20 with quick clamping nut**

The special quick-clamping nut allows the adjustment on the pulling spindle without a rotary movement but only by sliding.

① Scope of supply/single part overview see **chapter 2.2**

## 6. CARE AND STORAGE

### ATTENTION

Improper care and storage can damage the wheel bearing tool. **Never** immerse the wheel bearing tool in water, solvents, or other cleaning liquids. After use, clean all parts **only** with a dry and clean cleaning cloth. To protect against corrosion, rub all metal parts with a tool care oil or wax. Store the wheel bearing tool and the operating instructions at a dry and clean place.

## 7. REPAIR

### WARNING

For safety reasons, ensure that a damaged wheel bearing tool is no longer used! Professional inspection and repair may only be carried out by specially trained personnel from **GEDORE Automotive**. Improper repair can result in **DEATH** or **SEVERE INJURIES**.

## 8. ENVIRONMENTALLY COMPLIANT DISPOSAL

Dispose of the the wheel bearing tool and its packaging material in an environmentally compatible way in accordance with the legal requirements. If necessary, ask your local authorities about environmentally friendly disposal options.



## GEDORE-Werkzeugfabrik GmbH & Co. KG

Remscheider Straße 149  
42899 - Remscheid  
Postfach 120361  
47873 Remscheid  
GERMANY

### Vertrieb DEUTSCHLAND

☎ +49 (0) 2191 / 596-0  
☎ +49 (0) 2191 / 596-230  
✉ info@gedore.com  
🌐 www.gedore.com

### Sales INTERNATIONAL

☎ +49 (0) 2191 / 596-910  
☎ +49 (0) 2191 / 596-911  
✉ info@gedore.com  
🌐 www.gedore.com

## GEDORE TOOLS, INC.

Only for USA, Canada & Mexico  
Sólo para EE.UU., Canadá y México  
Seulement pour les USA, le Canada et le Mexique  
7187 Bryhawke Circle, Suite 700, North Charleston, SC 29418, USA

☎ +1-843 / 225 50 15  
☎ +1-843 / 225 50 20  
✉ info@gedoretools.com  
🌐 www.gedoretools.com

Worldwide GEDORE service centers and offices are listed on the Internet at: [www.gedore.com](http://www.gedore.com)

## GEDORE Automotive GmbH

Breslauer Straße 41  
78166 - Donaueschingen  
Postfach 1329  
78154 Donaueschingen  
GERMANY

### Vertrieb DEUTSCHLAND

☎ +49 (0) 771 / 8 32 23-0  
☎ +49 (0) 771 / 8 32 23-90  
✉ info.gam@gedore.com  
🌐 gedore-automotive.com



[www.gedore-automotive.com](http://www.gedore-automotive.com)