



KL-0056-11 EB

Shock Absorber Piston Rod Tool Kit





GEDORE Automotive GmbH

Breslauer Straße 41 78166 - Donaueschingen Postfach 1329 78154 Donaueschingen - GERMANY

€ +49 (0) 771 / 8 32 23-90 ♣ +49 (0) 771 / 8 32 23-90

info.gam@gedore.com

www.gedore-automotive.com











04/2024



Product instructions(Translation of the product instructions)



PRODUCT DESCRIPTION

KL-0056-11 EB - Shock absorber piston rod tool kit

Fits universally for MacPherson struts on passenger cars and vans.

For professional loosening or tightening of the piston rod nut and counter-holding of the shock absorber piston rod. Required, for example, when replacing the shock absorber or suspension spring.


- Extensive range of special sockets and screwdriver bits
- Matching drive parts included.

Recommended accessory: Reversible ratchet with 19mm hexagonal mount - 1993 U-20 SK





Product instructions





Scope of delivery/single part overview

		_		
Po	os.	Part no.	Description	Qty
A B		7 R 19	Open-ended spanner with ring ratchet, 19mm	1
		7 XL 10	Combination spanner, 10mm	1
•	C	Holder for screwdriver bits and sockets		
•	C1	KL-0056-1131	Holder for screwdriver bits 5/16"	1
	C2	KL-0056-1132	Holder for sockets 1/4"	1
	D Screwdriver bits 5/16"			
1	D1	KL-0056-1145	In-hex socket XZN12	1
ı	D2	KL-0056-1144	In-hex socket T50	1
ı	D3	KL-0056-1146	In-hex socket T40	1
ı	D4	KL-0056-1143	Screwdriver bit, size 7mm	1
ı	D5	KL-0056-1142	Screwdriver bit, size 6mm	1
ı	D6	KL-0056-1141	Screwdriver bit, size 5mm	1
	E Sockets 1/4"			
	E1	KL-0056-1156	Socket, 2-edge, 12mm	1
	E2	KL-0056-1155	Socket, 2-edge, 10mm	1
	E3	KL-0056-1154	Socket, 2-edge, 9mm	1
	E4	KL-0056-1153	Socket, 2-edge, 8mm	1
	E5	KL-0056-1152	Socket, 2-edge, 7mm	1
	E6	KL-0056-1151	Socket, 2-edge, 6mm	1
F Open side deep sockets		p sockets		
	F1	KL-0056-1122	Open side deep socket, size 22mm	1
	F2	KL-0056-1121	Open side deep socket, size 21mm	1
	F3	KL-0056-1119	Open side deep socket, size 19mm	1
	F4	KL-0056-1118	Open side deep socket, size 18mm	1
	F5	KL-0056-1117	Open side deep socket, size17mm	1
	F6	KL-0056-1116	SOpen side deep socket, size 16mm	1

Pos.	Part no.	Description	Qty
G	Lock nut spanner		
G1	KL-0050-51 A	Lock nut spanner (Mercedes)	1
Z	1993 U-20 SK	Reversible ratchet with 19mm hexagonal mount (available as an accessory!)	1
_	KL-0056-1190-1	Foam insert	1

Supplementary kit

KL-0056-1100 B

To supplement the shock absorber piston rod tool kit - **KL-0056-11 EA** to **KL-0056-11 EB**.

Pos.	Part no.	Description	Qty
D3	KL-0056-1146	In-hex socket T40	1
E3	KL-0056-1154	Socket, 2-edge, 9mm	1
E2	KL-0056-1155	Socket, 2-edge, 10mm	1
E1	KL-0056-1156	Socket, 2-edge, 12mm	1
F1	KL-0056-1122	Open side deep socket, size 22mm	1

Specifications

Open side deep socket:	Sizes 16/17/18/19/21/22mm
Screwdriver bit:	Sizes 5/6/7 mm/T40/T50/XZN12
Socket, 2-edge:	Sizes 6/7/8/9/10/12mm
Drive for open side deep sock	ets: Size 19mm
Drive of holder:	Size 10mm
Holder for screwdriver bits:	5/16"
Holder for sockets:	1/4"

A SAFETY INSTRUCTIONS AND REGULATIONS

- ▼Read and understand this product information before using the special tool, as it serves to familiarise you with the special tool and thus ensures safe use!
- **▼**Use the special tool **as intended** and **always** carry out maintenance and repair work in compliance with the regulations on occupational safety and accident prevention as well as the vehicle manufacturer's instructions!
- **▼ Before each use**, check the special tool **carefully** for damage, loose parts, or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- **▼ Always** wear your personal protective equipment, e.g. safety goggles, protective gloves, safety shoes, if necessary!
- ✓ Interrupt your work immediately if you are unsure about using the special tool, and contact GEDORE Automotive GmbH if necessary!
- ▼ Dispose of the special tool and its packaging material in an environmentally compatible way in accordance with the legal requirements. If necessary, ask your local authorities or GEDORE Automotive GmbH about environmentally friendly disposal options!




Produktanleitung(Originalfassung der Produktanleitung)



TYPICAL APPLICATION

This typical application describes how to assemble a shock absorber piston rod key.

1:Assemble the shock absorber piston rod key to fit...



- **1.** Assemble the shock absorber piston rod key to match the piston rod and piston rod nut as shown.
- (i) For other shock absorber piston rod keys, see the **GEDORE-Automotive** catalogue.



2: Typical application



AWARNING

Opening the piston rod nut on the suspension strut can cause the suspension spring to suddenly relax and spin around! This can cause **DEATH** or **SEVERE INJURIES**!

- ▼The piston rod nut must never be loosened before it or the suspension strut have been properly and safely clamped in a spring compressor!
- **2.** Before loosening the piston rod nut, clamp the shock absorber properly and securely in a suitable spring compressor according to the **manufacturer's specifications**.
- (i) Suitable spring compressors e.g. **KL-0015**, **KL-9002**, **KL-5501**, see **GEDORE-Automotive** catalogue.

Recommended accessories:

GEDORE 1993 U-20 SK - Reversible ratchet with 19mm hexagonal mount

Alternative to open-end spanner with ring ratchet [A]. Enables convenient drive of the shock absorber piston rod key. A space is already provided for this in the foam insert of the tool kit.