

KL-0148-711

Hook Spanner for Rear Axle Stop Buffer



GEDORE Automotive GmbH

Breslauer Straße 41
78166 - Donaueschingen
Postfach 1329
78154 Donaueschingen - GERMANY
☎ +49 (0) 771 / 8 32 23-0
✉ +49 (0) 771 / 8 32 23-90
✉ info.gam@gedore.com



www.gedore-automotive.com



11/2025

KL-0148-711__EN251011.indd

PRODUCT DESCRIPTION

KL-0148-711 - Hook spanner for rear axle stop buffer

Suitable for bolted stop buffers (spring travel limiters) on the rear axle of vehicles such as VW, Citroën, Opel, Vauxhall, Peugeot and Fiat.

Installed, for example, in VW Caddy III (2KA, 2KB, 2KH, 2KJ, 2CA, 2CB, 2CH, 2CJ), Caddy IV (SAB, SAJ), Caddy Alltrack IV (SAB, SAA); Citroen Jumper II (250); Opel Movano C (U9); Vauxhall Movano Mk3 (U9); Peugeot Boxer (250); Fiat Ducato II (244), Ducato III (250, 290) and others...

Suitable, for example, for stop buffers (spring travel limiters) with OE no. VW 2K0511153, 2K0511153B, 2K0511153E; Opel, Vauxhall 05166/A3; Opel, Peugeot, Citroen 5166.A3, 5166.97; Fiat 1357216080 or similar...

- The special hook spanner enables professional loosening and tightening of bolted stop buffers (spring travel limiters) on the rear axle.
- The precisely fitting profile guarantees exact guidance at the stop buffer and prevents slipping.
- The long lever ensures effortless power transmission and makes it easier to loosen and tighten the stop buffer.



Scope of delivery/single part overview

Part no.	Description	Qty.
KL-0148-711	Hook spanner for rear axle stop buffer	1

Technical data

Length: 420mm

Diameter: 110mm

Weight: 0.6kg

SAFETY INSTRUCTIONS AND REGULATIONS

- ▶ Read and understand this product information **before using** the special tool, as it serves to familiarise you with the special tool and thus ensures **safe use!**
- ▶ Use the special tool **as intended** and **always** carry out maintenance and repair work in compliance with the regulations on occupational safety and accident prevention as well as the vehicle manufacturer's instructions!
- ▶ **Before each use**, check the special tool **carefully** for damage, loose parts, or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- ▶ **Before each use**, check the moving parts on the **special tool** for dirt, if necessary clean and lubricate it **exclusively** with molybdenum disulphide paste, for example **KL-0014-0030!**
- ▶ **Always** wear your personal protective equipment, e.g. safety goggles, protective gloves, safety shoes, if necessary!
- ▶ Interrupt your work **immediately** if you are unsure about using the special tool, and contact **GEDORE Automotive GmbH** if **necessary!**
- ▶ Dispose of the special tool and its packaging material in an environmentally compatible way in accordance with the legal requirements. If necessary, ask your local authorities or **GEDORE Automotive GmbH** about environmentally friendly disposal options!