






KL-0369-305 A **Extraction Tool for Glow Elements**



(EN) **Product information**

A Read and understand before use!









www.gedore-automotive.com

GEDORE Automotive GmbH

GEDORE TOOLS, INC.

Only for USA, Canada & Mexico / Sólo para EE.UU., Canadá y México Seulement pour les USA, le Canada et le Mexique 7187 Bryhawke Circle, Suite 700 North Charleston, SC 29418, USA

(+1-843 / 225 50 15 gedore.com

Version 02/2023

0369-305A_EN220701.indd

Product information

(Translation of the product information)




Product description

KL-0369-305 A - Extraction tool for glow element

Suitable for glow plug tool kits, e.g. KL-0132-52 KB.

Required when boring out glow plugs, to pull out the glow element on the cylinder head.





Scope of supply/single parts overview

	ltem	Part no.	Description	Qty.
	Α	KL-0369-305-1	Extraction tool with pull bolt 1/4"-20 UNC, 185mm	1
	A1	KL-0369-3052	Collar nut	1
	A2	KL-0369-3050	Extraction tool (base unit)	1
	А3	KL-1383-2052	Pull bolt ¼"-20 UNC, 185mm long	1
	В	KL-1383-2242	Pull bolt no. 12-24 UNC, 165mm long	1

Specifications

For engine type:	Diesel
Size:6	+ 19mm
Overall length:	185mm

ASafety instructions and regulations

- **▶ Before using** the special tools, read and understand **all** safety instructions and follow them for **safe use**!
- ► Use the special tools **as intended, and** always perform maintenance tasks and repairs in compliance with the regulations on occupational safety and accident prevention and with the instructions by the vehicle manufacturer!
- ▶ Prior to each use, check the special tools carefully for damage, loose parts or unauthorised modifications. Never use it if you notice any such deficiencies!
- ▼ Always wear your personal protective equipment (for example safety goggles, protective gloves, safety shoes) when working!

Typical application

- **1.** First cut a thread in the **glow element tube** using a glow plug tool kit.
- 2. Now screw the matching pull bolt [A3] or [B] completely into the glow plug as shown in **©** 1.
- 3. Assemble the extraction tool as shown in 2
- **4.** Operate the collar nut **[A1]** clockwise while holding the tension bolt **[A3]** or **[B]** against it and pull out the glow plug on the cylinder head **© 2+3**.